

## vPad Pro with RFID Reader

Use two-factor authentication to release your SecurePrint print jobs



The vPad Pro with RFID Reader is a touch screen and RFID authentication device that is easy to install and integrate into your UniPrint Infinity printing environment. This device is compatible with all printer makes and models and therefore does not require printer fleet standardization. Simply use the printers you already have.

The perfect solution to enforce secure printing both in the head office and at all remote locations, the vPad Pro with RFID Reader also supports print stream compression. By utilizing print stream compression, remote print servers can be consolidated to the data centre. The data centre print server compresses print data before transmission and the remote office vPad decompresses the print stream before sending it to a user-selected printer. The vPad Pro with RFID Reader does not store any user or print job data, making this a truly secure printing solution.

### Technical Specification:

<b>CPU</b>	Freescall i.MX357, ARM11 processor, 532 MHz
<b>RAM</b>	128 MB SDRAM
<b>ROM</b>	512 MB NAND Flash
<b>Interfaces</b>	Two Ethernet ports, 10/100 Mbps Two USB 2.0 One serial interface RS232
<b>Screen Type &amp; Size</b>	7-inch resistive touch screen, TFT LCD (800 x 480)
<b>Dimensions</b>	9 x 6 $\frac{1}{8}$ x 1 $\frac{3}{4}$ inches (228.6 x 155.6 x 44.5 mm)
<b>Weight</b>	1.7 lbs (755 g)
<b>Color</b>	Top: Metallic grey; Base: Black
<b>Power Supply</b>	Output: 5V; Input: 100 – 240V
<b>Certifications</b>	FCC (Part 15, Sub B), CE (EN55024 & EN55022 Class A/B), QPS Mark (Safety EN60950)
<b>RFID Reader</b>	
<b>Frequency</b>	13.56 MHz
<b>Classifications Supported</b>	ISO14443A, ISO14443B, ISO15693 (Mifare Standard, Mifare Ultralight, Mifare DESfire, Vicinity, ICode SLI, SLE66cL)
<b>Certifications</b>	FCC, CE, UL, RoHS